

GraviTFlo Dosing System

The SaFTFlo® GraviTFlo Dosing System is a unique dispensing system featuring our closed loop technology in an inverted application. GraviTflo is the only solution of its kind and is ideal for areas without a water source or where water pressure is a concern.

Once the chemical bottle is placed on the dispenser, the insert valve opens to release chemicals into the reservoir of the dispenser. When the end-user is ready to dispense the concentrate for dilution, they simply press up on the dosing mechanism, and a metered amount of chemical concentrate empties into the receiving bottle, mop bucket, or other type of container.

Key Features

- **SAFETY** No chemical contact dispensing giving increased safety to operators. Uses closed loop technology.
- EASY INSTALL No water source needed to install or operate system
- LOW COST Low equipment costs and no maintenance costs or service calls
- **SIMPLE** Simple system that is easy to use and quick to educate others on
- ACCURATE DOSING Guaranteed accuracy for each and every dose
- ACCURATE DILUTION Accurate dilution ensures maximum product performance and cost effective use.
- **SUSTAINABLE** Closed loop system ensures enhanced saftey when transporting concentrated chemical preventing further leaks and spills
- **ADAPTABLE** Can be used for filling chemical bottles, mop buckets and compatible to an open feed system
- **VERSATILE** will fit any bottle size and be can installed into the smallest of places



Materials / Options

- Insert Size: 38mm
- Dosing sizes: 7mm, 15mm, 30mm, 45mm, 60mm
- Drip tray (To catch any dripping during dispensing)
- Hanging kit (Includes wall rail, clamps, and screws)
- For color and dosing cusomization, please contact your sales representative

For superior performance results, use GraviTFlo in conjunction with our full line of liquid containment and dispensing products from the SaFTFlo® Fluid Management Systems.





Phone: +1 402 455 8553 Fax: +1 402 455 8242 Toll Free: +1 800 759 7090



ADDRESS 7417 North 101 Street Omaha Nebraska 68122 USA





GraviTFlo Dosing System continued

Gravi	rFlo Insert Opti	ons
	Inches	мм
38mm	1.220	30.988
	1.240	31.496
	1.260	32.004
	1.280	35.512

	GraviTFlo	Dosing C)ptions	
1/4 ounce 7mm	1/2 ounce 15mm	1 ounce 30mm	1 1/2 ounce 45mm	2 ounce 60mm
	GraviTFlo I	Dispenser	Options	
Drip Tray	To cat	To catch any residual drips after dispensing		

Perfect for use in:





Hotels

Schools



Health Spa / Gym





Grocery Stores







ADDRESS 7417 North 101 Street Omaha Nebraska 68122 USA

